# MgO Primer

SPACETHERM® WALL LINER ACCESSORY

### **DESCRIPTION**

MgO Primer has been specially designed to negate the high absorption and super smooth surface of MgO board. When using Spacetherm WL, Primer can be used, dependant on the requirements of the user, to remove the suction for the board, preparing it for decoration, other than plaster finish. It is a technically advanced, high performance product which does not need mixing and can be applied in one coat. MgO Primer dries quickly dependant on climatic conditions, allowing the user fast progression to the next stage. For plaster finishes, please see Plasterbond datasheet

#### APPLICATION INSTRUCTIONS

All surfaces must be clean, sound and free from dirt, grease and other contaminants.

MgO Primer should be applied to Spacetherm WL using a brush, fine roller or sprayed on. Ensure that the whole surface is covered and wait to dry before preparing for decoration, other than plaster finish. Application of the next layer should always be carried out following the specific manufacturer's instructions.

MgO Primer does not need shaking or stirring and is supplied in a 5L ready to use container.

Do not dilute.

## LIABILITY

The information given is correct to the best of our knowledge at the time of publication but without guarantee of accuracy. We do not accept any responsibility for damage and claims arising from handling, transport, storage or disposal of the product. This safety data sheet applies only to the product named above supplied to the A. Proctor Group. If the product is used as part of other products, information given in the safety data sheet may be invalidated.

No warranty is hereby expressed or implied.



Spacetherm Wall Liner

#### **TECHNICAL DATA**

Condition	Ready to use liquid
Colour	White
Coverage	10m <sup>2</sup> /litre (normal ambient conditions)
pН	7.0 - 9.0
Health & Safety	Please see Material Safety Data sheet



Download a Spacetherm brochure from our website...

www.proctorgroup.com

